

Slimline Press Fit Escutcheon Installation Instructions

1. Insert the rubber O'ring #2 into the Slimline wall fitting #1.
2. Place the Slimline eyeball #3 on top of the O'ring #2.
3. Place the poly spacer #4 on top of the eyeball #3.
4. Center the Slimline escutcheon plate #5 over the face of the Slimline wall fitting #1, and tighten until snug.
5. Press metal escutcheon #6 firmly over plastic escutcheon plate #5.

Caution: Do not use abrasive or caustic cleansers on decorative escutcheons as they will damage the finish and void the warranty.

Diagram:

